



EEEC-371 Digital Signal Processing

Lab1 Report (Block Filtering)

ECE LEVEL 3

Team Members:

Ali Emad Abdel-Latif	19016028
Mayar Mohamed Mahmoud El-prince	19016749
Noha Mohamed Mahmoud El-Nemr	19016798
Hythem Ahmed shaaban	19016856
Yara Mohamed Nasser Hassan	19016873



In this lab, you try to understand the theory behind the Overlap-Add and Overlap-Save algorithms which are methods used to perform linear convolution in an easy way.

Overlap Add VS Overlap Save:

Overlap-add:


The overlap-add algorithm filters the input signal in the frequency domain. The input is divided into non-overlapping blocks which are linearly convolved with the FIR filter coefficients. The linear convolution of each block is computed by multiplying the discrete Fourier transforms (DFTs) of the block and the filter coefficients, and computing the inverse DFT of the product. For filter length M and FFT size N , the last $M-1$ samples of the linear convolution are added to the first $M-1$ samples of the next input sequence. The first $N-M+1$ samples of each summation result are output in sequence.

Overlap-save:


The overlap-save algorithm also filters the input signal in the frequency domain. The input is divided into overlapping blocks which are circularly convolved with the FIR filter coefficients. The circular convolution of each block is computed by multiplying the DFTs of the block and the filter coefficients, and computing the inverse DFT of the product. For filter length M and FFT size N , the first $M-1$ points of the circular convolution are invalid and discarded. The output consists of the remaining $N-M+1$ points, which are equivalent to the true convolution.

1- Overlap-save:


Block Diagram



Filter




Scope



2- Overlap-add:



Block Diagram




Algorithm:

1. In Simulink, Get a Sine wave with Amplitude 1 ,Frequency 100 Hz ,Sample time (1/8000)
2. Connect Buffer block with output size = 1548
3. Add Pad block , to pad with zeros , Column size = 2048
4. Get the FFT of the input sine wave and Filter coefficients h
5. Multiply both FFT outputs using product block X
6. Get the IFFT of the product result
7. Store the result of IFFT in Submatrix to discard all of the points that have been aliasing , with starting row index at:1548
8. This submatrix is added to the result of IFFT after delay , delay line with the same size as input L so set its size to 1549 ,Store it in Submatrix ,Pad the Submatrix results with zeros
9. After Addition , Add unbuffer block with size = 1548
10. View results on Scope.

Filter




Scope



Linear Convolution:

Block Diagram



Scope



Comment:

The overlap-save and overlap-add are methods to solve the linear convolution so scopes are similar.